


QUICK ACCESS MENU



Choosing '**Manage Display**' in the upper right corner helps personalize the tablet to your preferences.

