
QUICK ACCESS MENU: WI-FI



To locate and connect to available Wi-Fi networks, follow these simple steps:

- Choose Wi-Fi
- 2. Turn on Wi-Fi
- 3. View available wireless networks within range of your listed
- 4. Choose the network to which you want to connect (If the network is not listed, make sure the network is turned on and within range of the **CPR**³ tablet)
- If this screen appears, enter the password and choose CONNECT (If this screen does not appear, go to the next step)



The CPR³ tablet is now connected to the Wi-Fi network, and you can return to the Home screen. (Once connected to the Wi-Fi network, you can access the Internet via a web browser or apps.)



